

# INSTALLATION INSTRUCTIONS

## Pocket Mount #1 Installation:

Installation will require a bow press, as the limb bolt must be removed, and as such, your Authorized Bowtech Dealer should perform this installation.

1. Once the bow has been safely disassembled, unthread the bottom limb bolt from the barrel nut and remove.
2. Place the limb bolt through the mount with the "teeth" facing down.
3. Reinstall the limb bolt with the narrow side of the stand mount facing the front of the pocket as shown (fig. 1).
4. Safely reassemble the bow.



Fig. 1

## Pocket Mount #2 Installation:

Installation will require a bow press, as the limb bolt must be removed, and as such, your Authorized Bowtech Dealer should perform this installation.

1. Once the bow has been safely disassembled, unthread the bottom limb bolt from the barrel nut and remove.
2. Place the limb bolt through the mount with the adhesive pad facing down.
3. Reinstall the limb bolt with the narrow side of the stand mount facing the front of the pocket as shown (Fig.2).
4. Safely reassemble the bow.



Fig. 2

## Pocket Mount #3 Installation:

The mount can be directly bolted onto the bow pocket using the (3) screws provided in the hardware kit and a 3/32 Allen key. No bow press or additional adjustments needed.



Fig. 3

## 3rd Leg Installation:

If applicable, the 3rd leg mount can be directly bolted onto the bow with the provided screw and washer into the lower mount hole on the lower shooter-facing side of the riser with a 3/16 Allen key (as shown in Fig. 4).

Once installed, the 3rd leg can be installed into the mount by sliding the leg up between the limbs.



Fig. 4